

TUHM2(XC95m) SERIES REPAIR PARTS REV. 12/28/2018

PART NUMBER	DESCRIPTION	TUHMB060	TUHMB080	TUHMC100	TUHMD120
BLW00879	INDUCER BLOWER	X	X	X	X
BNR01077	BURNER	X	X	X	X
CNT06058	USER INTERFACE BOARD	X	X	X	X
CNT06883	VSIM DRIVE BOARD	X	X	X	X
CNT07080	CONTROL BOARD	X	X	X	X
IGN00152	IGNITER	X	X	X	X
MOD01574	PERSONALITY MODULE	X	X	X	X
MOT14415	MOTOR 1.0 HP				X
MOT14416	MOTOR 1/2 HP	X	X		
MOT14417	MOTOR 3/4 HP			X	
SEN01114	FLAME SENSOR	X	X	X	X
SEP00243	SEPARATOR TRAP	X	X	X	X
SWT01611	THERMAL LIMIT	X			
SWT01651	THERMAL LIMIT		X	X	X
SWT01714	DOOR SPST SWITCH	X	X	X	X
SWT02685	INDUCER LIMIT	X	X	X	X
SWT02978	INDUCER PRESSURE	X			
SWT02979	INDUCER PRESSURE		X	X	
SWT02980	INDUCER PRESSURE				X
SWT03073	PRESSURE SWITCH		X	X	
SWT03179	PRESSURE SWITCH				X
SWT03182	PRESSURE SWITCH	X			
SWT03525	FLAME ROLL OUT	X	X	X	X
TRR01729	TRANSFORMER	X	X	X	X
VAL10381	MODULATING VALVE	X	X	X	X