

TUH1(XT95) SERIES REPAIR PARTS REV. 12/28/2018

PART NUMBER	DESCRIPTION	TUH1B040	TUH1B060	TUH1B080	TUH1C100	TUH1D120
BLW00864	INDUCER BLOWER 1 STAGE		X			
BLW01137	INDUCER BLOWER 1 STAGE	X				
BLW01139	INDUCER BLOWER 1 STAGE			X	X	X
BNR01077	BURNER	X	X	X	X	X
CNT07737	CONTROL BOARD	X	X	X	X	X
IGN00145	IGNITER	X	X	X	X	X
MOT12244	MOTOR 1/2 HP	X				
MOT14391	MOTOR 1/2 HP		X			
MOT14392	MOTOR 1/2 HP			X		
MOT14393	MOTOR 3/4 HP				X	
MOT14394	MOTOR 1 HP					X
SEN01114	FLAME SENSOR	X	X	X	X	X
SEP00243	SEPARATOR TRAP	X	X	X	X	X
SWT01611	THERMAL LIMIT				X	
SWT01635	THERMAL LIMIT		X	X		
SWT01652	THERMAL LIMIT	X				
SWT01714	DOOR SPST SWITCH	X	X	X	X	X
SWT02124	FLAME ROLL OUT	X	X	X	X	X
SWT02685	INDUCER LIMIT	X	X			
SWT03220	PRESSURE SWITCH	X				
SWT03221	PRESSURE SWITCH		X			
SWT03254	PRESSURE SWITCH				X	
SWT03305	PRESSURE SWITCH			X		
SWT03324	PRESSURE SWITCH					X
TRR01729	TRANSFORMER	X	X	X	X	X
VAL09028	TX-VALVE	X	X	X	X	X